



MAILING

PO BOX 677
ROGERSVILLE, MO, 65742

SHIPPING

11 WHITE OAK ROAD,
ROGERSVILLE, MO, 65742

Scan QR Code for
More Information



www.p1mfg.com

(417) 753-5174



HEAD STUD KIT

KIT NUMBER

K004-H02S

APPLICATION

CHEVROLET 6.6L DURAMAX
DIESEL HEAD STUD KIT, L5P '17-
PRESENT ENGINES, 12PT NUTS,
S220 SERIES, BLACK OXIDE
FINISH

FASTENER INSTALLATION

1. Inspect kit contents for damage and confirm quantities.
2. Thoroughly clean all debris from engine block holes and threads.
3. Ensure all mating deck surfaces and fastener bearing surfaces are flat, free of debris and dry of any cleaning related products.
4. Inspect all deck gaskets for damage, fitment, & suitability.
5. Remove washers from packaging and remove rust preventative coating from all faces of washers, place on clean rag (petroleum-based solvent is recommended).
6. Remove remaining fasteners and place on clean shop rag, clean threads as required, (do not unnecessarily remove rust preventative).
7. Without lube, washers, gaskets or heads, thread studs into their intended holes by hand only until stud bottoms or thread run-out occurs (do not use tools). Achieving smooth installation without tools is necessary. Remove fasteners and clean or repair threads if needed.
8. Remove fasteners from their holes and apply TORQUEPOINT assembly lube to entire length of block end threads of the fastener using included brush. Work lube into threads all the way around the threaded sections so lube is nearly flush with outer diameter of thread face.
9. Install studs into block by hand or using hex key with light force only.
10. Thoroughly clean any visible fastener lube from mating surfaces and fit gasket and head on block and install washers onto studs. The washers should be dry during installation. DO NOT USE LUBE ON THE WASHERS.
11. Apply TORQUEPOINT assembly lube to entire length of nut end threads of the fastener using included brush. Work lube into threads all the way around the threaded sections so lube is nearly flush with outer diameter of thread face. Lube should be evenly distributed and not excessive.
12. Apply TORQUEPOINT lube to each nut's bearing surface only. Do not use lube on the washers. Install nuts with washers, hand tight. The washer should not rotate during torque procedure.

KIT CONTENTS

BBAS (12)	BOLT - MJ8x1.25, 12PT FLANGE, 10MM WRENCH, 4.53 [115.1] UHL, S220, BLACK OXIDE
SLKS (10)	STUD - MJ12X1.5 x MJ12X1.25 x 5.95 [151.1] OAL, S220, BLACK OXIDE
SJ1S (26)	STUD - MJ12x1.5 x MJ12x1.25 x 6.12 [155.4] OAL, S220, BLACK OXIDE
WD6T (36)	WASHER - FLAT - M12 NOMINAL x 1.000 O.D. x .12 THK, HARDENED & GROUND, BLACK OXIDE
NG1F (36)	NUT -12PT FLANGE, MJ12x1.25, 16MM WRENCH, .925 FL Ø, BLACK OXIDE
TP05 (2)	TORQUEPOINT FASTENER ASSEMBLY LUBE, 0.5oz TUBE
LBBR (1)	LUBE APPLICATION BRUSH

TORQUE RECOMMENDATION

Follow applicable OEM and/or aftermarket manufacturers suggested torque sequence & number of tightening steps.

Point One fasteners, paired with TORQUEPOINT fastener assembly lube, can sustain the following nominal torques and clamp loads while remaining below their minimum proof load rating.

*****DO NOT EXCEED THESE TORQUE INPUT VALUES*****

*****THESE VALUES WILL NOT BE APPLICABLE WHEN USING OTHER LUBRICANTS*****

BBAS

Torque: **30 ft-lbs**
Typical Clamp Load: **7000 lbs-force**

SLKS, SJ1S

Torque: **125 ft-lbs**
Typical Clamp Load: **19400 lbs-force**

Note: The number of aftermarket replacement parts and OEM combinations of components is numerous. Use caution as the clamp loads listed above may damage your assembly - use lower installation torques such as those provided by the manufacturer of your components if applicable.